



Crosbys Fryer Instruction Manual

Models

CRE- FRYCNTR – 4ltr Single
CRE- FRYANGLE – 6ltr Single
CRE- FRYDEEP – 2 x 6ltr Double

Thank you for purchasing your Crosbys Fryer. To make full use of the product please read this manual carefully before using the product and keep it safe for future reference.

Safety Tips

- If you find any damage when the product is unpacked, contact your Crosbys supplier within 24 hours of receipt of goods
- Always position on a flat stable surface
- Repairs should always be carried out by a qualified technician
- Do not use this product outside
- Clean immediately if oil/fat comes into contact with plastic components
- Ensure the oil level is between the MIN and MAX marks
- Change oil regularly
- Do not carry when hot
- Always switch off and unplug the unit before cleaning
- Do not cover the pan whilst frying
- Move by holding the product by the base
- Always store flat and do not store products on top of it
- If the power cord becomes damaged it must be replaced by a qualified technician
- This product is not designed to be used by persons with reduced physical or mental capabilities, lack of experience or knowledge, unless they are given suitable supervision, this includes children.

Pack Contents

- 1 x Crosbys Fryer
- 1 x Fry basket

Before Use

- Remove all packaging including all protective plastic, from your Crosbys Fryer
- Position on a flat surface
- Ensure the basket handle is securely in place
- Plug your Crosbys Fryer into the mains
- The fryer will now be ready to turn on

Operation

- Ensure the fryer is plugged in and the power is on
- Select the temperature you require, the yellow heating indicator light will start flashing
- Once the fryer has reached the desired temperature the yellow heating light will go out and the fryer is ready to use

Cleaning & Maintenance

- Before cleaning disconnect the fryer from the electricity supply.
- Once the unit has cooled down, the heating element can be removed and the fryer pan can also be removed for cleaning
- All other parts of the fryer can be cleaned with a damp cloth
- DO NOT submerge the fryer in water or use water sprays to clean it
- Always clean your Crosbys fryer daily, this will stop grease building up

and becoming difficult to clean.

Troubleshooting

Fault	Possible Cause	Solution
The power indicator light is not on	The unit is not switched on The plug or lead are damaged The fuse has blown	Check the unit is plugged in and switched on Contact your Crosbys distributor Replace the fuse
The unit is on, oil is not heating	Thermostat is too low Check oil level The heating element has failed	Adjust thermostat Add more oil if necessary Contact your Crosbys distributor
The fryer heats up but the indicator light is not on	Indicator light may need to be replaced	Contact your Crosbys distributor

Transportation and Storage

Please handle your fryer with care to prevent any damage to the unit and internal parts. The fryer should be stored somewhere which is ventilation and non-corrosive gas.

Do not store any flammable objects near the equipment.

Technical Information

CRE- FRYCNTR – 4ltr Single Fryer

Voltage 220~240v 50/60Hz

Power 2.0Kw

Weight 4kg

4ltr single tank fryer

Dimensions 217 x 400 x 320 mm

CRE- FRYNGLE – 6ltr Single Fryer

Voltage 220~240v 50/60Hz

Power 2.5Kw

Weight 5kg

6ltr single tank fryer

Dimensions 265 x 430 x 295 mm

CRE- FRYDEEP – 2 x 6ltr Double Fryer

Voltage 220~240v 50/60Hz

Power 2 x 2.5Kw

Weight 11kg

2 x 6ltr single tank fryer

Dimensions 550 x 430 x 295 mm

- Crosbys Fryer are supplied with a 3 pin plug and lead with a 13 amp fuse
- Appliance must be earthed
- If in doubt contact a qualified electrician or your Crosbys distributor

Disposal



Under WEEE regulations this product must not be disposed of as household waste. To prevent damage to the environment and humans this product must be disposed of in an approved and environmentally friendly recycling process. For more information on how to dispose of this correctly please contact your Crosbys distributor or local authority responsible for waste disposal.

Compliance



All Crosbys parts and products have under gone a stringent testing process to ensure that comply with the provisions of the relevant specific standards and all UK legislations.

Meanwhile, they also comply with all European standards and specifications. All Crosbys products carry the UKCA and CE approval symbols.